



Overview of Service Connection Requirements:

The following is a brief overview of Windermere Water & Sewer's requirements. The rates, terms and conditions for service are subject to change from time to time.

For more specific information, please contact the Utility offices at 250-342-6999, or stop by.

Remember that we require a minimum of 48 hours notice prior to scheduling any site meetings.

1. Fill out the Application for Service and return to the Utility.
2. Fill out the Water Connection and of Sewage Connection Application and pay any applicable fees.
 - **Water Service Pipes** are to be 20 or 25mm Blue 904 Pex Corporation Stop-Curb Stop and stand pipe.
 - o **Shut-off Valve/Stop Cock** to be installed at the point of entry of the water service connection inside the building.
 - o **Pressure Reducing/Regulating Valve** is required to be installed after the shut off valve, before the water meter.
 - o **Water Meter – a Neptune 5/8 x 3/4"**: T-10 meter with an E-coder R900i (m3) register is to be installed after the Pressure Reducing Valve and before the Check Valve/Backflow Preventor.
 - o **Check Valve/Backflow Preventor** is to be installed just past the meter assembly in order to protect the water system from contamination.
 - **Sewer Service Pipes**– as per the BC Plumbing Code.
 - o **Backflow Preventor** – to be installed on the pipe discharging into the Utility's system
 - o **Type of Service Needed** – Homeowner must contact the utility to determine if they will utilize an on-site grinder pump and force main or a gravity feed. This will determine the size of the pipe connection.
3. **Inspection:** Inspections for water and sewer connections must be completed by Windermere Water and Sewer staff prior to back filling of any connection points. Water must not be turned on at the Curb Stop prior to the interior inspection being performed AND approved.